

weber.floor 4817

Multi-use adhesive PVC/linoleum/textile

Wet-set adhesive for PVC floorings in sheets, CV, textile and linoleum floorings

Fields of application

For gluing textile floorings (tufting fabric with synthetic double backside or fleece backside, ball yarn, needle fleece, woven fabric), homogeneous/heterogeneous PVC floorings in sheets, CV floorings and linoleum floorings in sheets up to 2.5 mm thickness.

For use indoors.

Description

weber.floor 4817 is a factory-mixed, ready-to-use and solvent-free dispersion adhesive.

Main features

- EMICODE EC 1 PLUS: very low emission of volatile substances
- · GISCODE D1: solvent-free
- with official approval Z-155.20-552 (Germany)
- · excellent workability properties
- convenient for a wide range of floorings
- · good bonding strength
- suitable for shampooing according to RAL 991 A2
- · suitable on heated floor constructions
- suitable under chair castors according to EN 12529



Technical values

Flash-off time: approx. 5 - 25 minutes

Open time: approx. 25 minutes

Open to foot traffic: immediately

Open to full service (final strength): approx. 24 hours

Welding/filling of joints: approx. 24 hours

Temperature resistance (storage): +5°C - +30°C

Application temperature (room air): min. +18°C

Application temperature (substrate): min. +15°C

Consistency: medium vicosity

Quality control

weber.floor 4817 is subject to a regular internal quality control.

General notes

- Comply with the national standards and/or guidelines relating to laying works of floorings. If not issued, and if necessary, request technical advice.
- Relative humidity rate during application and drying: 40 65 %; max. 75%
- Adapt adhesive and flooring to room climate before application; the flooring must be free from tension.
- The flash-off, open and setting times depend on the temperature (room air and substrate), relative humidity rate, substrate porosity, type of flooring and adhesive amount.
- Observe the technical data sheets of the flooring and all other used products.
- · The adhesive is sensitive to frost.
- · Close opened packagings tightly and use their content quickly.

Special notes

- Neither install, nor move heavy furniture or objects on the new flooring, as long as the adhesive has not fully set.
- Avoid high temperatures caused by solar radiation.



Substrates

All norm-compliant and absorbent surfaces are allowed as substrates.

Substrate preparation

- The substrate must be load-bearing, dry, crack-free, free of adhesion-impairing layers and suitable for bonding.
- Before applying the adhesive, it is recommended to level out the substrate in order to obtain a smooth and uniformly porous substrate.
- If a thin levelling (approx. 1 10 mm) is required, use a **weber.floor** smoothing mortar, e.g weber.floor 4031 or 4032.
- If a thicker levelling (approx. 1 30 mm) is required, use a **weber.floor** levelling compound, e.g weber.floor 4160, 4190, 4310 or 4320.
- The substrate must be checked in accordance with the standards. In case of defects, concerns must be reported in writing.
- The substrate preparation must be adapted to the specific job site conditions.

Working instructions

- · Stir the adhesive well before use.
- Apply the adhesive in a uniform layer thickness with an appropriate notched spatula.
- We recommend to use following notch sizes (in mm) for the specific flooring.
- Notched spatula A 1: notch width 0.50 notch spacing 1.50 notch height 1.10
- Notched spatula A 2: notch width 1.30 notch spacing 1,70 notch height 1.40
- Notched spatula B 1: notch width 2.60 notch spacing 2.40 notch height 2.00
- Notched spatula B 2: notch width 2.00 notch spacing 3.00 notch height 2.55
- Avoid spots without adhesive or with accumulation of adhesive.
- Ensure that the adhesive is wetted over the entire surface of the back of the flooring in the form of ridges.
- Replace worn notched strips in good time.
- Do not apply more adhesive than can be laid with good wetting of the backside of the flooring within the open time.
- PVC and CV floorings: use the notched spatula A 1 or A 2.

3



- Textile floorings (e.g ball yarn) and linoleum floorings: use the notched spatula B 1 or B
- · After sufficient flash-off time or within the open time, lay the flooring into the adhesive bed and press down evenly to achieve complete bonding.
- · After laying, the flooring must be rolled on in crosswise motions; if necessary, repeat this operation.
- The welding/filling of the flooring joints can only be carried out after sufficient adhesion has been achieved.
- · Clean tools with water so long as the adhesive has not fully set. Hardened material must be removed mechanically.

Practical information			
Color: white			
Tools: Notched spatula A 1/A 2/B 1/B 2, depending on flooring type			
Storage: The product can be stored at least 15 months in its original unopened packaging, if kept protected from hymidity, and at temperatures between +5°C and +30°C	dry		

у, protected from humidity, and at temperatures between +5°C and +30°C.

Consumption / yield

approx. 200 - 550 g/m², depending on flooring, substrate and notch size

Packagings

Туре	Sales unit	Number / euro-pallet
Plastic bucket	13 kg	44 buckets

The information in this technical data sheet is based on our current knowledge and experience at the time of printing. However, they do not guarantee in the legal sense.